



- #1 U1-01 Wood Handle
- #2 U1AT-02 Hand Grip
- #3 U1-03 Face Iron
- #4 U1-04 Crossbar, Wood
- #5 U1-05 Tie Bolt, Complete
- #6 U1-06 Pendant Support w/ Hardware
- #7 U1-07 Steel Crossbar, Top
- #8 U1-08 3/8 Pin for Hangar Bar w/ Washer and Cotter Pin
- #8 U1-08 7/16 Oversize Pin for Hangar Bar w/ Washer and Cotter
- #9 U1-09 Hangar Bar
- #10 U1-10 Roller, Ball Bearing
- #11 U1-11 Roller Bolt w/ Washers and Nut
- #12 U1-12 Pendant
- #13 U1-13 Driver, Less Rollers, etc.
- #14 U1-14 Release Pedal w/ Rivet
- #15 U1-15 Link
- #16 U1-16 3/8 Pin For Links w/ Washers and Cotter Pins
- #16 U1-16 7/16 Pin For Links, Oversize w/Washers and Cotter Pins
- #17 U1-17 Steel Crossbar, Center
- #18 U1-18 Closing Pedal
- #19 U1-19 3/8 Pin for Pedal Pivot w/ Cotter Pin
- #19 U1-19 7/16 Pin for Pedal Pivot Oversize w/ Cotter Pin
- #20 U1-20-L Axle Bracket, Left w/ Set Screw
- #20 U1-20-R Axle Bracket, Right w/ Set Screw
- #21 U1AT-21 Axle
- #22 U1-22 Axle Collar w/ Set Screw
- #23 U1AT-23 Pedal Pivot w/ Set Screw, Pin, Bolt, & Nut
- #24 U1-24 Steel Crossbar, Bottom
- #25 U1AT-25-L Jaw w/ Point, Left
- #25 U1AT-25-R Jaw w/ Point, Right
- #26 U1AT-26 Point Only (Left or Right)
- #27 U1-27 Rub Iron
- #28 U1AT-28 Wheel - 8 X 2-1/2 w/ Bearings
- #29 U1-29 Replacement Ball Bearings (2 Per Wheel)
- #33 U1-33 Spring
- U1AT Hardware - Set of Bolts, Washers, and Nuts (16 each)