

Master Code Commands

CHANGE THE MASTER CODE

#Master Code ● 22 ● New Master Code ● New Master Code ● ●

Example: #2468 ● 22 ● 8642 ● 8642 ● ●

Result

Master Code has been changed to 8642

SET OR CHANGE THE USER CODE

#Master Code ● 42 ● User Code ● ●

Example: #2468 ● 42 ● 1455 ● ●

Result

New User Code 1455 now operative

DELETE THE USER CODE

#Master Code ● 44 ● ●

Example: #2468 ● 44 ● ●

Result

User Code deleted

SET OR CHANGE THE SUB-MASTER CODE

#Master Code ● 28 ● Sub-Master Code ● Sub-Master Code ● ●

Example: #2468 ● 28 ● 2255 ● 2255 ● ●

Result

Sub-Master Code 2255 now operative

DELETE THE SUB-MASTER CODE

#Master Code ● 20 ● 20 ● ●

Example: #2468 ● 20 ● 20 ● ●

Result

Sub-Master Code deleted

Sub-Master Code Commands

CHANGE THE SUB-MASTER CODE

#Sub-Master Code ● 40 ● New Sub-Master Code ● New Sub-Master Code ● ●

Example: #2255 ● 40 ● 8866 ● 8866 ● ●

Result

User Code deleted

SET OR CHANGE THE USER CODE

#Sub-Master Code ● 46 ● New User Code ● ●

Example: #2255 ● 46 ● 1455 ● ●

Result

User Code 1455 now operative

DELETE THE USER CODE

#Sub-Master Code ● 48 ● ●

Example: #2255 ● 48 ● ●

Result

User Code deleted

User Code Commands

CHANGING THE USER CODE

#User Code ● New User Code ● ●

Example: #1455 ● 5541 ● ●

Result

User Code now 5541

POI-1000-V01



Programming & Operating Instructions

CODELOCKS LTD UK

Tel: +44 (0) 1635 239645

Fax: +44 (0) 1635 239644

sales@codelocks.co.uk

Helpline, service & spares

FREEPHONE 0800 393 405

CODELOCKS CHINA

Tel: +86 757 8660 1981-3

Fax: +86 757 8660 1980

sales@codelocks.cn

CODELOCKS US

Tel: +1 714 979 2900

Fax: +1 714 979 2902

sales@codelocks.us

Help: 1.877.CODELOCK

www.codelocks.com

CODES - the Basics

- Cabinet Locks are supplied with the factory set master code 2,4,6,8
- **When fitted immediately change to a new master code**
- All codes are four digits long
- To help remember and program codes each of the 5 buttons is identified with two digits. This allows all digits (1,2,3,4,5,6,7,8,9,0) to be used and easily remembered in a code sequence
- The lock 'open' time is set at 4 seconds

FUNCTIONS
Before programming select the most appropriate function for the application.

A) REPEATED USE
Important Note: This is the default function and is already pre-programmed in new locks.

The same User Code is entered to open the lock every time.

This is the most common function and is used where the **same code** will be repeatedly used.

B) SINGLE USE
The User enters a single use code which will lock and then open the lock **once only** and then be erased.

This function is used for short term, multi occupancy applications e.g. a locker in a leisure centre.

To select **B)** single use:
Master code ● 24 ● #1111 ● 1111 ●

The lock will now remain open until the next single use code is entered into the lock as follows:
Step 1 # enter 4 digit code ● close the locker which will now be locked.

Step 2 Enter same 4 digit code ● lock will open and remain open, 4 digit code is erased.

Example:
Step 1 # 1992 ● close the locker which will now be locked.
Step 2 1992 ● lock will open and remain open, code 1992 is erased.

The lock will now remain open until the next single use code is entered.

Note: To reset to default function **A)** use the following key sequence:
Master Code ● 26 ● Master Code
Example: #2468 ● 26 ● 2468

OPERATING INSTRUCTIONS

Note: The Cabinet Lock has a 5 button keypad and a # button. The # button is hidden beneath the handle when in the locked position.

The lock has the following code levels:

Master Code can:
Open the lock
Change the Master Code
Set / Change / Delete the Sub-Master and User Code
Select between repeated use and single use codes

Sub-Master Code can:
Open the lock
Change the Sub-Master
Set / Change / Delete / the User Code

User Code can:
Open the lock
Change the User Code

A code cannot be programmed into more than one level

Lost Code Procedure

Note: The procedure requires the door to be open

- Remove the rear-fixing bolt and swing the lock over the edge of the door to reveal the battery compartment.
- Remove one battery.
- Press and hold the 1 button, replace the battery, the blue LED will flash twice, release the 1 button. Within three seconds press the 1 button three times. The blue LED will flash twice and the lock will have reverted to the factory master code 2468 and all other stored settings will be erased.

Penalty time


- Entering three incorrect codes will cause the lock into shutdown for 10 seconds.

Battery Power

The Cabinet Lock should provide well in excess of 15,000 openings, of 4 seconds each, from 2 x AAA 1.5v cells.

Low Battery

When the battery power is low the Red LED will flash 3 times before the Blue LED flashes to signal acceptance of the code. Batteries should be changed as soon as this happens.
The lock will operate for 100 times with low battery.



Battery failure override

The Cabinet Lock has been designed so an external PP9 battery can be placed against the contact points surrounding the Blue and Red LED's so the lock can be opened to replace the batteries should they fail.

The procedure is as follows:

- Place the contact points of the PP9 battery against the contact points surrounding the Blue and Red LED's.
- The positive + PP9 terminal against the Red LED contact point and the negative – PP9 terminal against the Blue LED.
- Enter the Master Code.
- The motor will withdraw the locking pin allowing the lock to be opened.
- Fit new batteries by removing the upper fixing bolt and swinging the lock down over the edge of the door. Refit the lock.

PROGRAMMING

To program – the lock must be in the open position with the # button visible. Every program command must commence by pressing the # button, followed by either the Master Code, Sub-Master Code or User Code.

